#### Electrical Machines and Power Electronics Lab

## **Experiment-2**

## **Operating characteristics of DC Motor**

Group: W02

### **Experiment-2A**

#### AIM:

To study and plot the operating characteristics of (Torque vs Speed & Armature current vs Speed) of DC shunt motor.

#### **Procedure:**

- 1. Firstly we Ensured that no load is connected to the motor and made connections as shown in fig 1 without powering the circuit.
- 2. Kept the Rheostat in the Field circuit at minimum resistance position resistance.
- 3. Kept the Rheostat in the Armature circuit at maximum resistance position resistance.
- 4. Increased the DC voltage from zero to rated voltage on field side circuit using SCR actuator slowly.
- 5. Adjusted the Rheostat in the Armature circuit to get rated voltage across the armature circuit.
- 6. Now slowly started loading the Motor.
- 7. Maintained constant voltage (rated voltage) across the armature circuit by adjusting the Rheostat in the Armature circuit for every reading.
- 8. For each set of loading, we note down the corresponding values of T 1 and T2, armature current and speed.
- 9. Calculated the load torque. Make sure that armature current does not exceed the rating of the motor.

#### Circuit Diagram:




Fig 1: Connection Diagram for Armature voltage control and field control method of speed

## **Machine Specifications:**


Radius of motor shaft was measured to be 7 cm (approximately).


### **Precautions:**

- 1) Make sure the connections were made properly.
- 2) For the speed control analysis make sure some load is connected, and the tension belt is intact with the rotor.
- 3)Do not touch the rotor while it is rotating with a high RPM.
- 4) Do not wear loose clothes while conducting this experiment.

### **Observations:**

V	l(armature)	T1	T2	T=9.81*r*(T1-T2)	Speed(rpm)
180	0.3	0.1	0.1	0	1500
180	0.4	0.5	0.2	0.20601	1490
180	0.6	1	0.2	0.54936	1485
180	0.8	1.5	0.3	0.82404	1472
180	0.9	2	0.5	1.03005	1461
180	1	2.5	0.7	1.23606	1444





## **DC Series Motor**

#### AIM:

To study and plot the operating characteristics of (Torque vs Speed & Armature current vs Speed) of DC series motor.

#### **Procedure:**

- 1. We Ensured that some load is connected to the motor. Without powering the circuit, made connections as shown in fig. 2.
- 2. Increased the DC voltage from zero to rated voltage gradually.

- 3. Slowly started loading the Motor by belt arrangement provided. For each set of loading, we note down the corresponding values of T 1 and T 2, armature current and speed.
- 4. Calculated the Torque.
- 5. We Made sure that armature current does not exceed the rating of the motor.
- 6. Plotted the characteristics of the DC Series motor.

#### Circuit Diagram:






Fig 2 Connection diagram for DC series Motor

### **Observations:**

V	l(armature)	T1	Т2	T=9.81*r*(T2-T1)	Speed
120	1.7	1.5	2.5	0.6867	1330
120	2.1	2	3.9	1.30473	1078
120	2.4	2.5	5.3	1.92276	945
120	2.5	2.6	5.9	2.26611	900





## **Experiment-2B**

# **Speed Control of DC Shunt Motor**

## a) Armature control

<u>Aim:</u>

To control the speed of given shunt motor below rated speed by armature control method

### **Procedure:**

- 1. Made connections as shown in Fig 1
- 2. Kept the Rheostat in the Armature circuit at maximum resistance position resistance.
- 3. Kept the Rheostat in the Field circuit at minimum resistance position resistance.
- 4. Increased the DC voltage to get rated field current on field side circuit using SCR actuator slowly.
- 5. Adjusted the Rheostat in the Armature circuit to get rated voltage across the armature circuit.
- 6. Increased the resistance of rheostat in the Armature circuit in steps and recorded the speed for various armature Voltage






Fig 1 Connection diagram for DC shunt Motor

Armature Voltage(V)	Speed(rpm)
180	1520
170	1440
160	1330
150	1260
140	1170
130	1110



# **B)** Field control

Field Current(A)	Speed(rpm)
0.45	1490
0.4	1590
0.35	1640
0.3	1730
0.2	1800



## **Results and conclusion:**

- →After the experiment we observed and concluded that the torque increases linearly with increase in the armature current.
- →Also concluded that speed is inversely proportional to the armature current, i.e., if armature current is increased the speed will decrease.
- →Speed can be controlled by changing the terminal voltage. Gain in speed can be observed by increasing the terminal voltage.
- →By reducing the field flux, increase the speed of the motor is observed. That shows that they are inversely proportional.